
R.S.F.O. GUIDE SIGNS with EXIT PANELS



BACK VIEW OF ADVANCE GUIDE SIGNS WITH EXIT NUMBER PANEL SIGN SHOWING INSTALLATION OF ANGLE IRON

NOTE: WHEN EXIT PANEL IS SUPPORTED BY MULTIPLE POST, 2 ANGLE IRONS ARE REQUIRED. SIGN WILL EXTEND 6 INCHES ABOVE SUPPORTS

ANGLE IRON DETAIL