
GUIDE SIGNS with EXIT PANELS



BACK VIEW OF ADVANCE GUIDE SIGNS
WITH EXIT NUMBER PANEL SIGN
SHOWING INSTALLATION OF ANGLE IRON

NOTE: WHEN EXIT PANEL IS SUPPORTED BY MULTIPLE POST, 2 ANGLE IRONS ARE REQUIRED. SIGN WILL EXTEND 6 INCHES ABOVE SUPPORTS

ANGLE IRON DETAIL